

All Liteplan's Standard emergency products are fitted with a charge indicating LED.

A Solid Green light indicates that the Battery Charge is healthy.

Self-Test and DALI emergency products are fitted with a Bi-Colour LED and indicate as follows:

- A Solid Green light indicates that the Battery Charge is healthy.
- A Green Flashing light indicates that the unit is in pre-commissioning mode, or there is either a Function or Duration Test in progress or that a test has taken place recently
- A Red Flashing or Red Solid light indicates that there is a fault on the unit.



Please refer to following chart below for more complete descriptions/fault indication:-

		DLP	MST	Model NDA	NES	DNA
LED Indicates						
Green Solid	Mains On No Fault	●	●	●	●	●
	48h Pre-Commissioning	Not Applicable	Not Applicable	Not Applicable	Not Applicable	●
	Function Test In Progress	●	●	●	●	●
Green Flash	Duration Test In Progress	●	●	●	●	●
	Duration Test Passed	●	Not Applicable	Not Applicable	Not Applicable	Not Applicable
Red Solid	Lamp Fault	●	Not Applicable	Not Applicable	Not Applicable	Not Applicable
	Battery Fault	●	●	●	●	●
Red Flash	Lamp Fault	Not Applicable	●	●	●	●
	LED Driver Fault	●	Not Applicable	Not Applicable	Not Applicable	Not Applicable
LED Off	Mains Failure Battery OK	○	○	○	○	○
Red/Green Alternate	DALI Mode Identification	●	Not Applicable	●	Not Applicable	●